

Rowe pumps owners manual

Models: RPM2 / KD24




ROWE CAFS LLC
PO BOX 300
WASHINGTON, AR. 71862
PHONE # 870-777-8848
EMIAL—rowecafs@gmail.com
WEB—www.cafssystems.com

TABLE OF CONTENTS:

PAGE

- 1 Specs and performance
- 2 Pump breakdown
- 3 Pump part numbers
- 4 Drive components breakdown and part numbers
- 5 SS panel option
- 6 Warranty

ROWE RPM2/KD24 PERFORMANCE AND SPECS



Engine: Kubota D902 24hp diesel engine

Liquid cooled

Tier 4

12 volt electric start

Pump: Rowe RPM2 pump

Anodized aluminum pump body and volute

Type III class 2 black hard anodized -as per MIL-A-8625F

Brass clearance rings

Bronze impeller, 1" threaded shaft Ceramic mechanical pump shaft seal

Performance:

100 GPM @ 150 PSI 200 GPM @ 100 PSI 300 GPM @ 25 PSI


Discharge: 4 bolt flange

Suction: Changeable flanges for 3" FNPT / 4" VIC combo flange 3" VIC beveled flange

Base: Kubota leg kit



ROWE RPM2-KD24 PUMP BREAKDOWN






ROWE RPM2-KD24 PUMP REF. TO PART NUMBER

REF QTY PART# DESCRIPTION

| | | 11111 | DESCRIPTION |
|---------|------------|-------------|--------------------------------------|
| A | 1 | RPU001 | RPM2 PUMP BODY |
| В | 4 | RPU004 | SS SEALING WASHERS |
| С | 4 | RPU011 | 3/8" X 3-1/4" SS CAP SCREW |
| D | 2 | RPU002 | BRASS CLEARANCE RING |
| Е | 1 | RPU005 | O-RING, VOLUTE |
| F | 1 | RPU010 | 1-1/2" MECHANICAL SEAL |
| G | 1 | RPB001 | 1" THREADED RPM2 IMPELLER, LESS 1/4' |
| Н | 11 | RPU009 | SS CLAMPING RING |
| I | 1 | RPU003 | RPM2 VOLUTE |
| | | | |
| PARTS I | LISTED BEI | LOW ARE NOT | SHOWN ON DIAGRAM. |
| N/A | 1 | RPU006 | O-RING, SUCTION ADAPTOR |
| N/A | - | RPU007 | 3" FNPT / 4" VIC SUCTION ADAPTOR |
| N/A | - | RPU008 | 3" VIC SUCTION ADAPTOR |
| N/A | 6 | RPU012 | 5/16" X 3/4" SS SOCKET HEAD BOLTS |
| N/A | 3 | 3152X4 | 1/4" BRASS HEX HEAD PLUG |
| | | 1220 | 1/4" BRASS DRAIN PLUG |



ROWE RPM2-KD24 DRIVE COMPONENTS




REF QTY PART# DESCRIPTION

| A | N/A | N/A | KUBOTA ENGINE FLYWHEEL |
|-------------|-----|-----------|--------------------------------|
| В | 1 | 131704 | DRIVE DISC |
| С | 2 | 1288 | SEALED BEARINGS |
| D | 1 | RM0012 | IMPELLER SPACER |
| Е | 1 | 131703 | PUMP SHAFT |
| F | 1 | 129929 | BEARING SPACER |
| G | 1 | 129926 | BEARING CARRIER/ ADAPTOR PLATE |
| | 1 | 930114-02 | ALUMINUM HOUSING |
| | | | |



ROWE RPM2-KD24 SS PANEL OPTION



PANEL IS 5" TALL X 12.25" LONG

| <u>REF</u> | <u>QTY</u> | PART# | DESCRIPTION |
|------------|------------|--------|-----------------------|
| ٨ | 1 | PM0002 | KD24 DIIMD DANEI DANE |

| A | 1 | RM0002 | KD24 PUMP PANEL, PANEL ONLY |
|--------------|----|--------|-------------------------------|
| В | 1 | RPU015 | 2.5" 0-300PSI PRESSURE GAUGE |
| С | 1 | 1002 | LED PANEL LIGHT |
| D | 4 | 1078 | RED LED INDICATOR LIGHTS |
| Е | 1 | 1044 | ON/OFF ROCKER SWITCH |
| F | I | 1284 | THROTTLE CONTROLLER AND CABLE |
| G | 1 | 1097 | ENGINE STOP SWITCH |
| <u>H</u> | 11 | 95033 | GLOW/START SWITCH |
| | | | |

ROWE RPM2 WARRANTY POLICY

Rowe CAFS LLC, warrants products of its manufacture to be free from defects in material and workmanship, under normal use and service, for a period of seven (7) years of usage. Rowe CAFS LLC warrants products to the original purchaser only. Products used for rental or contracting purposes are warranted for a period of six months of usage. This limited warranty is effective only if the equipment or apparatus is used as directed, is not subject to misuse, negligence or accident, and is not altered, treated or repaired by someone other than Rowe CAFS LLC or its designee. Items not manufactured by Rowe CAFS LLC shall bare only the limited warranties offered by their respective manufacturers.

This exclusive remedy for breach of this warranty shall be to give Rowe CAFS LLC written notice thereof and to request a Return Goods Authorization, the buyer will return the non-conforming material to Rowe CAFS LLC F.O.B. its plant within thirty days after the buyer has received the R.G.A. Thereupon Rowe CAFS LLC at its own election shall repair or replace the same or repay the price thereof. No proximate, incident, consequential or other damages shall be recovered.

Rowe CAFS LLC shall not be liable for consequential damages or contingent liabilities including; but not limited to, loss of life, personal injury, loss of crops, loss due to fire or water property damage, and consequential trade or other commercial loss arising out of failure of Rowe CAFS LLC products.

Detatch and return the below to activate warranty.

Mail to: ROWE CAFS LLC, PO BOX 300, WASHINGTON, AR. 71862

ROWE CAFS LLC PUMP WARRANTY ACTIVATION CARD

| <u> FIRE DEPT / COMPA</u> | NY NAME : | | |
|---------------------------|---------------|------|--|
| CONTACT: | - | | |
| PHONE: | EMAIL: | | |
| ADDRESS | | | |
| CITY | STATE | ZIP | |
| PUMP MODEL PURC | CHASED | | |
| DATE PURCHASED | | | |
| DATE PLACED INTO |) SERVICE | | |
| TYPE OF APPARATU | J S | | |
| | | | |
| SIGNATURE | | DATE | |

